


PD800

# dokoo E-Collar Anti-Tugging

Instruction Guide

REF.NO.P20P24M01D09




We recommend attaching the leash to the dog's harness instead of the collar strap. Attaching the leash to the collar strap may cause


Avoid leaving the collar on the dog's neck for more than 18 hours

discomfort or even injury to the dog. Please use it with caution.

We recommend repositioning the collar on the dog's neck every 1 to




1.The collar strap without D-ring is only for connecting to the receiver, it is strictly forbidden to attach the leash to the collar strap Anti-Tugging Dog Training Collar Reciever with the receiver.




2. The leash should be attached to the dog harness, if you don't have it, please wear one more collar strap with D-ring on your dog's neck and attach the leash to it.


# **Dog Training Collar Identication**



#### The Anti-Tugging Dog Training Collar Package Includes




#### Power On




## Display Identication

**Button Identication** 




### **Auto Mode**



power button

Double tap "o" icon to check collar battery life: Device will automatically send a "Beep+Static Shock ( M ) " signal when dog pulls to 5 lbs. 2 Beeps = 40% 1 Beep = 20% Red light will ash 10 seconds Device will automatically send a "Beep+Static Shock ( L ) " signal when dog pulls to 7 lbs. indicating battery life too low = shutting down

### Switch from Manual Mode to Auto Mode





With Power On, press and release the power button once to switch from Manual to Auto. (Press again to switch back)

energy, the device will switch to manual mode automatically if there is no operation within 30 minutes in auto mode.

### **Adjust the Static Shock Level** (Manual Mode Only)




Press the static shock or beep button

+"or"-" button to adjust vibration from Level 1 to Level 9

1. When the device is in auto mode, press the "+" or "-" button to adjust the static shock level directly.

2. The display screen of the device will be off and goes to sleep if there is no operation within 60 seconds, and it can resume to work by pressing any function button.




Press"+"or"-" button to adjust vibration from Level 1 to Level 9


Use short probesfor short haired dogs

The static shock is very mild and it will not hurt the dogs. It's design to get their attention and should always be follow by a verbal

Always begin training on Level 1 and work up to a proper level inaccordance with your dog's size and temperament.



The USB charging port for the control handle can be found on the side as indicated in the photo.




The USB charging port for the collar receiver can be found on th

You are ready to begin using the Anti-tugging Dog Training Collar, please read our instructional guides for training tips.

NOTE:

To test for static shock, place the tester on the probes make sure the wires in the tester slots contact the probes. Then press the static shock button on the control handle and the tester will light up.

The anti-tugging dog training collar must be in manual mode for



Collar should be adjusted to be snug but not too tight around dog's

For the best fit, you should be able to put one finger between the collar and your dog's neck.

3

Press the vibration button

Device will automatically send a "Beep+Static Shock (s)" signal when dog pulls to 3 lbs.

**Adjust the Vibration Level** 

Wanua⊡ Vibration Levels ✓ Wanual:1

When the device is in the Auto mode, the Manual mode still works.

Use long probesfor long haired dogs

Long Rubber Probe Covers

bottom by lifting the rubber tab.